

Series	Model	Export Limit	Consumption Monitoring	Consumption Monitoring and Export Limit	Notes
XS PLUS	GW1500-XS-11	CT-90	HK1000	HK1000	For multiple inverters one CT-90 is required per inverter for export limit. Only one meter is required for consumption monitoring.
	GW2000-XS-11				
	GW2500-XS-11				
	GW3000-XS-11				
DNS G3 (With NPS)	GW3000-DNS-30	CT-90	(GM1000)	(GM1000)	For multiple inverters one CT-90 is required per inverter for export limit. Only one meter is required for consumption monitoring.
	GW4200-DNS-30				
	GW5000-DNS-30				
	GW6000-DNS-30				
MS G3 (With NPS)	GW5000-MS-30	CT-90	(GM1000)	(GM1000)	For multiple inverters one CT-90 is required per inverter for export limit. Only one meter is required for consumption monitoring.
	GW6000-MS-30				
	GW8500-MS-30				
	GW10K-MS-30				
SDT G2	GW8KAU-DT	GM3000	HK3000	HK3000	For installation with multiple inverters use SEC1000. CT's are not included.
	GW10KAU-DT				
	GW15KAU-DT				
	GW20KAU-DT				
SDT G2 Plus	GW5000-SDT-20	GM3000	HK3000	HK3000	For installation with multiple inverters use SEC1000. CT's are not included.
	GW6000-SDT-20				
SMT	GW25K-MT	GM3000	HK3000	HK3000	For installation with multiple inverters use SEC1000. CT's are not included.
	GW29.9K-MT				
	GW36K-MT				
MT G2	GW50K-MT	GM3000	HK3000	HK3000	For installation with multiple inverters use SEC1000. CT's are not included.
	GW60K-MT				
	GW80K-MT				
HT	GW100K-HT	GM3000	HK3000	HK3000	For installation with multiple inverters use SEC1000. CT's are not included.
	GW110K-HT				
	GW120K-HT				
ET (Hybrid)	GW5KL-ET	GM3000	GM3000	GM3000	For installation with multiple inverters use SEC1000S. CT's are not included.
	GW6KL-ET				
	GW8KL-ET				
	GW10KL-ET				
ET (Hybrid)	GW15K-ET	GM3000	GM300	GM3000	Installation of multiple inverters is not supported. GM3000 capable to 120 amps.
	GW20K-ET				
	GW25K-ET				
	GW29.9K-ET				
EH PLUS (Hybrid)	GW3600N-EH	GM1000	GM1000	GM1000	Meter is not included in packaging with EH Hybrid Ready version.
	GW5000N-EH				
	GW6000N-EH				
ES G2 (Hybrid)	GW5000-ES-20	GM1000	GM1000	GM1000	
	GW6000-ES-20				
SBP G2 (Hybrid)	GW5000-SBP-20	Wont request export limit on SBP	GM1000D	GM1000D	GM1000D supplied with SBP. It comes with two CTs, one for solar, one for main incoming cable
	GW6000-SBP-20				
BTC (Hybrid)	GW50K-BTC	GM3000C	GM3000C	GM3000C	CT's not included.
ETC (Hybrid)	GW50K-BTC	GM3000C	GM3000C	GM3000C	CT's not included.